

# urbania

UNIQUE  
WALLCOVERING

**WIDTH** 27" (68.5 cm)

**ROLL LENGTH** 15 linear yards (13.5 meters) untrimmed

**FACING** Polyester/metal film (with a water-based plaster surface effect)

**BACKING** Non-woven

**PATTERN MATCH** Non-reverse hang, random match

**FIRE TEST** ASTM E-84 Tunnel Test: Class A, flame spread 15, smoke developed 15 (test procedure is comparable to UL 723)

**MINIMUM** Each order is individually crafted. **Material is not stocked.** Order by the yard after 30 yard (27.5 meter) minimum is met. Please allow 3-4 weeks for delivery.

**SPECIAL NOTE** As with all handmade wallcovering, color variation is normal. Since each order is individually handcrafted, **NO RETURNS WILL BE ACCEPTED.**

Please be aware that this wallcovering may interfere with broadcast signals, such as Wi-Fi and radio reception. While interference is possible because of the polyester/metal layer in this specific construction, tests have shown a 5% or less impact on signals when the receptor is totally encased in wallcovering.

**ADDITIONAL PRODUCT ATTRIBUTES** Water-based inks

**CUSTOM CAPABILITIES** Custom colors are available

**SPECIAL INSTALLATION INSTRUCTION** Wallcovering shall be installed by experienced workers and contractors in strict accordance with these instructions. Material must be dry table trimmed. Hang rolls in sequence, do not reverse. **DO NOT DOUBLE CUT.** Apply material to wall using a soft brush, plastic smoother, or drywall blade wrapped with a soft cloth to lay out the material. When smoothing, work from the center out to the edges. To avoid trapping air bubbles, use an oval seam roller to butt seams. Wash smoothing brush and seam roller often, as an accumulation of paste on tools may mark or scratch the material. Completely clean adhesive off the surface after each strip is hung. Wash seams with a damp sponge and clean, warm water. Change rinse water often. Any adhesive left on the surface can cause flaking. Dry carefully with a soft cloth or chamois.

This wallcovering contains metallic particles and will conduct electricity. To avoid possible fire hazards or electric shock, wallcovering should not come in contact with or extend into electrical-outlet boxes or light-switch boxes. Turn off all electricity to the room prior to starting installation.

