

Install Instructions

Digital Wallcovering



Installation is one of the most critical pieces of the puzzle to ensure your digital printed wallcovering murals are installed without a flaw. If you have any questions about the installation process, please call before continuing.

WALL PREP BEFORE INSTALLATION

- Prepping for a digital mural installation is the same as prepping for a commercial wallcovering application
- It is very important to ensure you have the proper primer for installation
- The walls should be dry, clean, smooth, and free of imperfections
- Check with your manufacturer or NGPP (Natl Guild of Professional Paper Hangers) for recommended primers or adhesives

IMPORTANT INFORMATION

If at any time before or during installation you do not understand these instructions, or if a discrepancy is discovered in pattern, color, or quality, STOP. Contact your distributor before proceeding. Any deviation from these Application Instructions will void the manufacturer's warranty.

Carefully examine all material to ensure correct pattern, color, and quantity.

Digital Wallcoverings must be installed under permanent lighting conditions. Temperature for area receiving digital wallcovering must be maintained 60°-80° F and no more than 50% relative humidity, for six days prior to and after installation.

All rolls are numbered consecutively. Panels must be cut and installed in sequence. All panels should be numbered and hung in sequence as they are cut from the roll. If there is a variation in color and/or pattern effect, discontinue hanging and contact your distributor immediately. MANUFACTURER IS NOT BE RESPONSIBLE FOR CLAIMS BEYOND THREE PANELS.

INSTALLATION

There are many differences between installing a digital mural and installing a commercial wallcovering application. Open mural and inspect all panels for any imperfections before installing the mural. No labor charges will be considered once cut.

- Each mural is printed for a specific wall.
- One panel cannot be removed from a mural and replacement panels added from another mural or roll to fit original location.
- Placement of the first panel is critical, review manufacturer layout and mark seam locations on wall before hanging first panel.
- Laser Level should be used to line up the printed edge of the mural to the wall.
- Bleed varies between vendors, each panel has alignment marks for top and bottom of each panel. (typical bleed/overlap is 1-2")
- Lay panels out onto the floor to match properly. Mark matching points with painters tape on the panels.
- With marked wall at seam locations and Laser Level, install first panel of the mural. Continue panel sequence.
- Double cut the seam closest to the matching edge of the overlap approximately 1/4".
- Remove materials and excess adhesive. Clean with mild soap, warm water and wipe with a microfiber cloth.

Please contact your local sales representative or the Momentum Digital Team at digitalcustoms@momtex.com with any questions.



MOMENTUM
TEXTILES & WALLCOVERING