

## Installation Guide

---

### HANGING INSTRUCTIONS FOR SOURCE ONE PERFORMANCE NUFELT WALLCOVERING

#### INSTALLATION:

1. Inspect wall surfaces to ensure they are structurally sound and free of dirt, grease, and markings.
2. Clean off any debris and markings and ensure surface is dry before beginning installation process.
3. Carefully inspect all rolls (rolls are shipped separately in heavy duty poly bags) and we will not be responsible for damage after goods are cut.
4. Material is designed to be dry hung (do not use a pasting machine).
5. Apply a premixed, heavy-duty vinyl wallcovering adhesive directly to the wall and allow it to dry overnight. (IMPORTANT: Adhesive is ready mixed and should not be diluted. DO NOT APPLY PASTE TO THE BACK OF THE WALLCOVERING.
6. Once the first coat of wallcovering adhesive is completely dry, apply a second coat of undiluted adhesive to the wall and allow the adhesive to dry until it has a slight tack- ability to the touch.
7. Wallcovering should be hung straight up without alternating strips (All seams should be vertical, nap going the same way, and at least six inches away from the inside or outside of corners). For best results, apply full widths of material wherever possible. Headers and doors may cause shading.
8. Begin hanging by cutting the first wallcovering strip to the desired length, adding 2 inches for overlap onto ceiling and 2 inches for overlap onto base. Material is not factory trimmed – it is necessary for installer to cut a straight edge. All edges must be butt joined.
9. Continue to install a second and third strip following the same process as with the first strip. Inspect the three strips for color, uniformity, and proper application. Continue installation, stopping to inspect for product correctness and proper application every three strips. If a problem is detected after any three strips are applied, STOP WORK IMMEDIATELY and call Customer Service. (Shading is normal due to the lustrous needle-punch pile and should not be considered a defect).

## Cleaning Guide

---

### CLEANING GUIDE FOR SOURCE ONE PERFORMANCE NUFELT WALLCOVERING

**GUIDE TO CLEANING MULTI-USE FELTED FABRIC** Through installation procedures or consumer use, fabric may become soiled and require spot cleaning from time to time. The following information is provided as a guideline for the care and cleaning of this product. Because this material is made from synthetic fibers, it cleans very well with virtually no damage to the color or construction itself. Most commercially available Carpet and Upholstery cleaners will do an excellent job removing stains. From time to time, additional cleaning methods may need to be employed to remove stubborn or difficult stains.

**CLEANING WITH BLEACH** Our acoustic nonwoven wallcoverings may be cleaned with bleach solutions as outlined by the CDC recommendations for disinfecting walls. The Center for Disease Control recommends a 2% bleach to 98% water mixture. We've tested our products with a 10% bleach to 90% water mixture without any damage.

#### CLEAN & DISINFECT

1. Make sure fabric is dry and has been vacuumed.
2. Allow proper ventilation during and after application.
3. Prepare a 10% bleach solution in water.
4. Make sure floor and trim are covered or taped.
5. Apply the cleaning solution using a misting spray bottle. Solution will absorb into the acoustical fabric.
6. Allow cleaning solution to linger on the fabric for at least 1 minute.
7. Wipe fabric thoroughly to remove residual cleaning solution.
8. Wear disposable or washable gloves.
9. Allow fabric to air dry.
10. Repeat process as necessary.

**GENERAL** As with any stain or contamination, the quick response is the best, especially when done in conjunction with the proper cleaner for the type of stain. **IMPORTANT:** Make sure you have selected the right cleaning agent from the list below before you begin the cleaning process. The categories of stains listed below are based on 1) stains acquired during OEM manufacture and 2) acquired by consumer/end-user following installation of fabric.

#### OEM FABRIC INCIDENTS

Type of Stain	Cleaning Agent	How to Remove
Oil	high strength detergent	soak-blot dry
Adhesive (water based)	detergent	scrub-rinse-blot dry
Adhesive (solvent based)	mineral spirits	soak-blot dry
Felt Tip Marker (indelible)	detergent	scrub-rinse-blot dry
Ink (ball point indelible)	dry clean solvent	soak-blot dry
Pencil (graphite lead)	detergent	scrub-rinse-blot dry
Chalk	detergent	scrub-rinse-blot dry
Paint (latex)	high strength detergent	scrub-rinse-blot dry
Paint (oil)	solvents/mineral spirits	soak-blot dry
Stains (latex)	high strength detergent	scrub-rinse-blot dry
Stains (oil)	solvents/mineral spirits	soak-blot dry
Tar/Asphalt	K-1 kerosene/solvents	soak-blot dry

Note: In many cases listed above, repeated steps may be required to fully extract the contaminant from the material. Use solvent type cleaners in a well-ventilated area.

Note: Always check to see that the cleaner will not cause damage to material or fabric by testing on a small area out of sight.

## Cleaning Guide

---

### CONSUMER/END USER INCIDENTS

Type of Stain	Cleaning Agent	How to Remove
Mustard	dry clean solvent	scrub-soak-blot dry
Ketchup*	high strength detergent	scrub-rinse-blot dry
Coffee*	high strength detergent	scrub-rinse-blot dry
Chocolate*	detergent	scrub-rinse-blot dry
Tea*	high strength detergent	scrub-rinse-blot dry
Chewing Gum	dry clean solvent	scrub-soak-blot dry
Oil	high strength detergent	scrub-soak-blot dry
Grease	high strength detergent/degreaser	scrub-soak-blot dry
Tar/Asphalt	K-1 kerosene/thinner	scrub-soak-blot dry
Wax	detergent	hot iron-on detergent-soaked towel or cloth
Rust	rust remover	soak-rinse-blot dry
Dirt*	detergent	scrub-rinse-blot dry
Lipstick	dry clean solvent	soak-blot dry
Nail Polish	dry clean solvent	soak-blot dry
Shoe Polish	dry clean solvent	soak-blot dry
Crayon	high strength detergent	scrub-rinse-blot dry
Vomit*	high strength detergent	scrub-rinse-blot dry-deodorize with vinegar
Urine*	high strength detergent	scrub-rinse-blot dry-deodorize with vinegar
Blood*	high strength detergent	scrub-rinse-blot dry
Excrement*	high strength detergent	scrub-rinse-blot dry-deodorize with vinegar

Note: In many cases listed above, repeated steps may be required to fully extract contaminant from material. Items listed above with (\*) may also be removed through steam extraction method by a professional cleaner or service.

Note: Always check to see that the cleaner used will not cause damage to the material or fabric by testing on an area out of sight.

Important: The recommendations made above are done in good faith and are based on a history of actual experiences and laboratory evaluations. The manufacturer and/or its designated distributor does not warrant, either expressed or implied, the effectiveness of the cleaning agents listed and the process for cleaning described above.