

## Installation Guide

---

### HANGING INSTRUCTIONS FOR SOURCE ONE HANDCRAFTED WALLCOVERING

All wall surfaces should be structurally sound. Sand finished plaster should be smoothed. In order to insure good adhesion, old wallcovering and loose

**THESE WALLCOVERINGS ARE ALL HANDCRAFTED AND VARIATIONS SHOULD BE EXPECTED THROUGHOUT THE ROLL. ALTHOUGH EXTREME CARE IS TAKEN DURING MANUFACTURING, VARIATIONS IN SHADE AND TEXTURE ARE TO BE EXPECTED.**

**FINAL INSPECTIONS ARE THE RESPONSIBILITY OF THE USER.**

**WE WILL NOT ACCEPT ANY CLAIMS FOR CUT MERCHANDISE OR LABOR, EVEN IF THE WALLCOVERING IS DEFECTIVE.**

**THE INSTALLER SHOULD STEP BACK AND EXAMINE THE WALLCOVERING AFTER EVERY FEW STRIPS TO ENSURE THE DESIRED EFFECT IS ACHIEVED.**

#### CHECK BEFORE CUTTING:

Before cutting and hanging, check pattern name and number to match product(s) ordered. NO CREDIT for labor charges will be allowed for cutting or hanging wrong colorways or patterns. Be sure that there is sufficient material to complete the job. Should you have any questions, contact your distributor before proceeding. NO RETURNS will be accepted after the material is cut.

#### WALL PREPARATION:

Previous wallcovering must be removed. Walls must be structurally sound, dry, sealed and clean prior to installation. Wall surfaces should be free from defects and imperfections that could show through the finished covered surface. Walls should be smooth and clean and prepared with a latex primer or wall prep. Walls should be washed with detergent or bleach to kill any bacteria that could cause mildew. New construction may have lime which should be neutralized with a coating of zinc sulfate (one pound to one gallon of water) and allowed to dry completely.

#### TRIMMING:

Handcrafted wallcoverings are usually cut into strips and dry trimmed. Do not double cut. Take care to trim accurately. Heavy texture might show through as white when trimmed. Be sure edges are even before installation. Each shipment contains bolts marked with consecutive numbers. This is the order in which the wallcovering was produced, hence, this is the order in which the bolts **must** be hung. Example: from bolt 1, hang the first strip, then hang the second strip from bolt 1, then the third strip from bolt 1, etc. Continue with this same procedure for the remaining bolts.

#### ADHESIVE:

You **MUST** use a quality grade heavy-duty premixed clear vinyl non-staining adhesive with a low water content. **Do not dilute. Using another type of adhesive will be solely at the risk of the installer.** Wallcovering is not strippable or peelable. Prepare walls using strippable adhesive if wallcovering is to be removed at a later date. Apply an even coat of adhesive to the back of the wall covering using a soft nap roller. Allow the adhesive to become tacky. **(Please be advised that different sub-straights may need slightly more or slightly less booking time to achieve the proper tack.)** Additionally, if required, pre-paste the wall, allow wall to tack and then apply strip. Completely clean adhesive off the surface after each strip is hung. Any adhesive left on the surface can cause flaking. When removing paste from the surface, try to avoid excessive rubbing or pressure. Use a mild soap or detergent to clean the wallcovering.

#### TEST HANGING:

Test hang three panels and carefully review materials and application. If satisfactory, continue the installation. If not, contact your distributor.

## Installation Guide

---

### INSTALLATION:

The manufacturer assumes no responsibility for the installation of material beyond three panels. The manufacturer will not be responsible for labor. Wallcovering should be installed by experienced workers and contractors in strict accordance with these instructions. Material must be dry table trimmed. **DO NOT DOUBLE CUT.** Apply material to wall using a soft brush, plastic smoother, or drywall blade wrapped with a soft cloth to lay out the material. When smoothing, work from the center out to the edges. To avoid trapping air bubbles, use an oval seam roller to butt seams. Wash smoothing brush and seam roller often, as an accumulation of paste on tools may mark or scratch the material. Completely clean adhesive off the surface after each strip is hung. Wash seams with a damp sponge and clean warm water. Change rinse water often. Any adhesive left on the surface can cause flaking. Dry carefully with a soft cloth or chamois.

### MAINTENANCE:

Stains should be removed immediately – wipe-off with a clean sponge or rag (slightly damp). Use a mild detergent to clean the wallcovering. Do not soak. Avoid excess rubbing or pressure so as to not damage the finish.