

Installation Guide

HANGING INSTRUCTIONS FOR SOURCE ONE SPECIALTY WALLCOVERING

BEFORE YOU START

Carefully inspect all materials and make certain that the pattern and color are exactly as ordered.

No claims will be accepted for cut/installed material beyond the installation of 1 roll, or after 14 days of delivery.

SURFACE PREPARATION

Remove all existing wallcovering, backing paper, paint, and all surface contaminations. Ensure the surface is smooth and dry.

Make sure to match the color to the wall when using drywall compound.

Apply primer/sealer and allow to dry.

ADHESIVE

We recommend using a heavy duty, clear wallcovering adhesive.

HANGING

Paste the back of the wallcovering. Do not use a paste machine. Book for 5-15 minutes to let adhesive penetrate the material.

Do not crease the paper when folding length and do not pile after pasting.

Work quickly and, using a spatula or a brush, gently smooth the paper onto the wall.

Joints should be tightly butted. Material ships pre-trimmed. Gently use the seam roller to finish off the joint. Avoid excessive seam rolling as this may cause damage.

Avoid getting adhesive onto the surface of the wallcovering. Immediately wipe off any excess paste with a soft, damp cloth and then with a dry cloth. Do not rub or use a sponge as it may damage the surface of the wallcovering.