

# Installation Guide

---

## HANGING INSTRUCTIONS FOR SWIRL WALLCOVERING

### SURFACE PREPARATION:

<b>New Construction</b>	The General Contractor shall see that the surfaces are true, smooth, level finish, free from ricks, dirt, dust, irregularities or rough spots. Walls are to be thoroughly dry before application. A good quality acrylic primer-sealer should be used to seal walls for easy future removal.
<b>Renovation</b>	Remove old wallpaper. Check wall surfaces to ensure that it is smooth, clean and dry. Enamel paint should be dulled and sealed. Old paint should be checked for sound adhesion. For any other surfaces, check with your local representative.

### APPLICATION:

1. Before cutting, examine pattern, color and shade lots to determine that they matches approved samples. No allowances will be given for cut material. Hand made sand paper requires extra care to install.
2. A heavy-duty clear adhesive should be used by the wallcovering contractor. Care must be taken not to allow paste on the face of the material.
3. Cut material in consecutive bolt sequence as marked on end of each wrapper.
4. Use strips in exact order as they are cut from roll. Fill in over doors and windows as you come to them with strips but in consecutive order from the roll.
5. Paper-backed natural materials require a minimum of 5-8 minutes booking time (pasted sheets folded together) to allow expanding of materials. Do not allow paste to come in contact with the face of the material. Should bubbles occur while hanging, check carefully the amount of booking time allowed
6. Smooth material to hanging surface with soft bristle brush to eliminate air bubbles and ensure adhesion being careful not to get adhesive on the face of the material
7. Completely avoid washing material with water.
8. AFTER APPLYING THREE STRIPS, if there are any variations in color and/or pattern match, this should be immediately communicated to the distributor representative for his inspection before proceeding further with installation. Natural hand-made wallcoverings will tend to lightly panel on occasion and variations are inherent in the material.

### CLEANING:

No adhesive must come in contact with the face of this material. If cleaning is necessary, avoid rubbing.

### SPECIAL NOTE:

These wallcoverings have been manufactured to the highest quality standards possible. However, it should be noted that some items by their nature, require care in handling and installing so as to provide an acceptable wall finish.

All materials are manufactured to width 36"/38" and untrimmed.