



tri kes

HANGING INSTRUCTIONS FOR SOURCE ONE SPECIALTY TANGLE

SURFACE PREPARATION:

NEW CONSTRUCTION

The General Contractor shall see that the surfaces are true, smooth, with a level finish, and free from cracks, dirt, dust, irregularities or rough spots. Walls are to be thoroughly dry before application. A good quality acrylic primer-sealer should be used to seal walls for easy future removal.

RENOVATION

Remove old wallpaper. Check wall surfaces to ensure that it is smooth, clean and dry. Enamel paint should be dulled and sealed. Old paint should be checked for sound adhesion. For any other surfaces, check with your local representative.

APPLICATION:

1) Before cutting, examine pattern, color and shade lots to determine that it matches approved samples. No allowances will be given for cut material.

2) A heavy-duty clear adhesive should be used by the wallcovering contractor.

3) Paper-backed fiber materials require a minimum of 5-8 minutes booking time (pasted sheets folded together) to allow materials to expand. Should bubbles occur while hanging, check carefully the amount of booking time allowed. DO NOT crease when booking material, as damage will occur.

4) Cut material in consecutive bolt sequence as marked on end of each wrapper. Reversing strips may reduce shading at the seams. Fill in over doors and windows as you come to them with strips cut in consecutive order from the roll. Use one blade per cut.

5) Table trimming with straight edge on cutting table is recommended. All materials should be table trimmed to 36" regardless of visible selvedge. Use caution to keep paste off face of material.

6) Smooth material to hanging surface with a soft bristle brush to ensure good adhesion.

7) AFTER APPLYING THREE STRIPS, if there are any variations in color and/or pattern match, this should be immediately communicated to the distributor representative for inspection before proceeding further with installation. Natural wallcoverings will tend to lightly panel on occasion.

CLEANING:

All stains should be treated as soon as possible with clean water by using a soft cloth (white) or clean sponge. For more difficult situations a mild detergent solution of warm water can be used being careful not to flood the surface. Abrasive rubbing should be avoided. More care should be taken in cleaning dark colors due to the possibility of causing "light marks". Occasional vacuuming may aid in maintaining the product's fresh look.

SPECIAL NOTE:

These wallcoverings have been manufactured to the highest quality standards possible. However, it should be noted that some items by their nature, require care in handling and installing so as to provide an acceptable wall finish.